

SHARP PARTS GUIDE

MODEL ER-A490

(for KA, KB, TQ, TR, TS)

PRINTER: PR-58M: KA, KB
PR-58A: TQ, TR, TS

CONTENTS

- | | |
|-----------------------------------------------|------------------------------------------|
| 1 Top cabinet etc. | 7 Display PWB unit |
| 2 Bottom cabinet etc. | 8 IR PWB unit |
| 3 Drawer box unit(SK423 type)
[for KA, KB] | 9 Pop-up PWB unit |
| 4 Packing material & Accessories | 10 ROM/RAM PWB unit |
| 5 Main PWB unit | 11 Articles for consumption |
| 6 Key I/F PWB unit | 12 Service route options & Service tools |
| | ■ Index |

Because parts marked with “△” is indispensable for the machine safety maintenance and operation, it must be replaced with the parts specific to the product specification.

Table of destinations

SELECTION CODE	COUNTRIES
U	U.S.A., Guam
A	Canada
TS	Germany
TQ	SEEG territory other than Germany (Stamp: English)
TR	SEEG territory other than Germany (Stamp: Spanish)
KB	U. Kingdom
KA	Australia

SELECTION CODE	COUNTRIES
K	Korea

SELECTION CODE	COUNTRIES
RA1	Morocco, Algeria, Tunisia, West Africa
RA2	Chile, Uruguay, Peru, Argentina, Paraguay
RA5	Sri Lanka

SELECTION CODE	COUNTRIES
RB3	Indonesia
RB4	
RB5	Cyprus
RB6	Panama
RB7	Barbados
RB8	Malaysia (U.S.A. version)

SELECTION CODE	COUNTRIES
RC1	Malaysia (Europe version)
RC2	Singapore
RC5	Dominican Republic, Ecuador

SELECTION CODE	COUNTRIES
SB	Saudi Arabia (127V area)
SBA	Saudi Arabia (220V area)
SC	Taiwan
SD	Venezuela
SE	Hong Kong
SG	Lebanon, Syria, Greece, Pakistan, Iran, Egypt, Thailand, Iraq, Mauritius, Seychelles, Tahiti, Jordan, Sudan, Turkey
SH	South Africa (U.S.A.version)
SHE	South Africa (Europe version)
SJ	Phillippines (Europe version)
SJ2	Phillippines (U.S.A. version)
SM	Kuwait, Qatar, Oman, UAE, Malta, Bahrain
SMT	Nigeria, Yemen, Kenya

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)