


SHARP SERVICE MANUAL


CODE: 00ZERA490VSME

ELECTRONIC CASH REGISTER

MODEL ER-A490



For KA/KB



For TQ/TR/TS

SRV Key : LKGIM7113BHZZ
PRINTER : PR-58A: For TQ/TR/TS
PR-58M: For KA/KB
(For "V" version)

CAUTION

EXTREME CAUTION MUST BE TAKEN WHEN SERVICING THIS MACHINE. EVEN THOUGH THE MODE SWITCH IS IN THE OFF POSITION, VOLTAGE IS STILL SUPPLIED TO THE ENTIRE MACHINE.

WHEN WORKING ON THIS MACHINE MAKE SURE THAT THE POWER CORD IS REMOVED FROM THE WALL OUTLET.

CONTENTS

CHAPTER 1. SPECIFICATIONS	1
CHAPTER 2. OPTIONS	5
CHAPTER 3. SRV. RESET AND MASTER RESET	8
CHAPTER 4. HARDWARE DESCRIPTION	9
CHAPTER 5. TEST FUNCTION	33
CHAPTER 6. DOWN LOAD FUNCTION	39
CHAPTER 7. CIRCUIT DIAGRAM & PWB LAYOUT	41

PARTS GUIDE

Parts marked with "!" is important for maintaining the safety of the set. Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

SHARP CORPORATION

This document has been published to be used for after sales service only.
The contents are subject to change without notice.

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)