

# SHARP SERVICE MANUAL

CODE: 00ZERA510VSME



## ELECTRONIC CASH REGISTER

## MODEL ER-A510

SRV Key : LKGIM7113RCZZ  
PRINTER: M-820  
(For "V" version)

**CAUTION**  
EXTREME CAUTION MUST BE TAKEN WHEN SERVICING THIS MACHINE. EVEN THOUGH THE MODE SWITCH IS IN THE  $\odot$  POSITION, VOLTAGE IS STILL SUPPLIED TO THE ENTIRE MACHINE.  
WHEN WORKING ON THIS MACHINE MAKE SURE THAT THE POWER CORD IS REMOVED FROM THE WALL OUTLET.

### CONTENTS

CHAPTER 1. SPECIFICATIONS .....	1
CHAPTER 2. OPTIONS .....	5
CHAPTER 3. SRV. RESET AND MASTER RESET .....	8
CHAPTER 4. HARD WARE DESCRIPTION .....	9
CHAPTER 5. TEST FUNCTION .....	27
CHAPTER 6. DOWN LOAD FUNCTION .....	36
CHAPTER 7. SERVICE PRECAUTION .....	38
CHAPTER 8. CIRCUIT DIAGRAM & PWB LAYOUT .....	40

### PARTS GUIDE

Parts marked with " $\triangle$ " is important for maintaining the safety of the set. Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/sharp/ER-A510 service manual.html](https://the-checkout-tech.com/manuals/sharp/ER-A510%20service%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)