


SHARP PARTS GUIDE

CODE : 00ZERA520UPGE



ER-A520 MODEL ER-A530

PRINTER : PR-58HM

(U/A version)

CONTENTS

- 1 Top cabinet etc.(ER-A520)
 - 2 Top cabinet etc.(ER-A530)
 - 3 Bottom cabinet etc.
 - 4 Drawer box unit(SK-423 type)
 - 5 Packing material & Accessories
 - 6 Main PWB unit
 - 7 Key I/F PWB unit
 - 8 CN I/F PWB unit
 - 9 Pop up PWB unit
 - 10 Articles for consumption
 - 11 Service options & Service tools
- index

Parts marked with "△" are important for maintaining the safety of the set. be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/sharp/ER-A520 ER-A530 parts guide U and A ve](https://the-checkout-tech.com/manuals/sharp/ER-A520%20ER-A530%20parts%20guide%20U%20and%20A%20ve)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)