


SHARP PROGRAMMING MANUAL

CODE : 00ZERA520UPME



ELECTRONIC CASH REGISTER

ER-A520 MODEL ER-A530

(For "U/A" version)

CONTENTS

CHAPTER 1. SERVICE (SRV) MODE	1 - 1
CHAPTER 2. READING OF THE SRV MODE PROGRAM	2 - 1
CHAPTER 3. SERVICE MODE PROGRAMMING	3 - 1
CHAPTER 4. OP X/Z, X1/Z1, X2/Z2 MODE	4 - 1

* For settings related to the USER PROGRAMMING mode, please refer to the applicable Instruction Manual provided for the ER-A520 and ER-A530 model cash registers.

Parts marked with "△" are important for maintaining the safety of the set. Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/sharp/ER-A520 and ER-A530 programming man](https://the-checkout-tech.com/manuals/sharp/ER-A520%20and%20ER-A530%20programming%20man)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)