


SHARP INSTALLATION MANUAL

CODE: 00ZERA550IMVE




ELECTRONIC CASH REGISTER

MODEL ER-A550

SRV Key : LKGIM7113RCZZ
PRINTER: M-820
(For "V" version)

CAUTION

EXTREME CAUTION MUST BE TAKEN WHEN SERVICING THIS MACHINE. EVEN THOUGH THE MODE SWITCH IS IN THE  POSITION, VOLTAGE IS STILL SUPPLIED TO THE ENTIRE MACHINE.

WHEN WORKING ON THIS MACHINE MAKE SURE THAT THE POWER CORD IS REMOVED FROM THE WALL OUTLET.

CONTENTS

| | |
|--|----|
| CHAPTER 1. GENERAL | 1 |
| CHAPTER 2. LIST OF OPTIONS | 1 |
| CHAPTER 3. REMOVING THE TOP CABINET AND MAIN DRAWER | 2 |
| CHAPTER 4. REMOVING THE TOP CABINET | 2 |
| CHAPTER 5. EXPANSION RAM CHIP (ER-01RA, ER-02RA) | 4 |
| CHAPTER 6. CONTROL ROM (ER-A55R1) | 6 |
| CHAPTER 7. IN-LINE & RS232 I/F (ER-A5IN) RS232 I/F (ER-A5RS) | 7 |
| CHAPTER 8. REMOTE DRAWER (ER-02DW) | 18 |
| CHAPTER 9. SLIP PRINTER (ER-31SP) | 20 |
| CHAPTER 10. ONE HOLE CASHIER KEY (ER-A5CL) | 23 |
| CHAPTER 11. JOURNAL NEAR END SENSOR (DKIT-8643RCZZ) | 24 |
| CHAPTER 12. DRAWER FIXING KIT (DKIT-8633RCZZ) | 25 |
| CHAPTER 13. PRESETS LOADER | |

Parts marked with "△" is important for maintaining the safety of the set. Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)