

SHARP PARTS GUIDE

CODE:00ZERA570U2U4

ER-A570(U2/U4) MODEL ER-A610(U2/U4)

PRINTER:M-820

For U2 : 220V

For U4 : 240V

CONTENTS

- 1 Top cabinet etc.(ER-A570U2/U4)
 - 2 Top cabinet etc.(ER-A610U2/U4)
 - 3 Bottom cabinet etc.
 - 4 Drawer box unit(SK460 type)
 - 5 Packing material & Accessories
 - 6 Main PWB unit
 - 7 Display PWB unit
 - 8 Power supply PWB unit
 - 9 Noise filter PWB unit
 - 10 Pop-up PWB unit
 - 11 RS232C I/F PWB unit
 - 12 Articles for consumption
 - 13 Special service tools & Service options
- Index

Because parts marked with "⚠" is indispensable for the machine safety maintenance and operation, it must be replaced with the parts specific to the product specification.

SHARP CORPORATION

This document has been published to be used for after sales service only.
The contents are subject to change without notice.

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/sharp/ER-A570 and ER-A610 parts guide manual](https://the-checkout-tech.com/manuals/sharp/ER-A570%20and%20ER-A610%20parts%20guide%20manual)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)