# SHARP   INSTALLATION MANUAL

ELECTRONIC CASH REGISTER

MODEL ER-A570

SRV Key : LKGIM7113RCZZ
PRINTER : M-820
(For "V" version)

CAUTION
EXTREME CAUTION MUST BE TAKEN WHEN SERVICING THIS MACHINE. EVEN THOUGH THE MODE SWITCH IS IN THE & POSITION, VOLTAGE IS STILL SUPPLIED TO THE ENTIRE MACHINE.
WHEN WORKING ON THIS MACHINE MAKE SURE THAT THE POWER CORD IS REMOVED FROM THE WALL OUTLET.

CONTENTS

Parts marked with "! " is important for maintaining the safety of the set. Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

SHARP CORPORATION

This is a "Table of Contents preview" for quality assurance

The full manual can be purchased from our store:
https://the-checkout-tech.com/manuals/sharp/ER-A570 installation manual.html

And our free Online Keysheet maker:
https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/

HTTPS://THE-CHECKOUT-TECH.COM