

## SHARP INSTALLATION MANUAL

CODE: 00ZERA610VIME

## **ELECTRONIC CASH REGISTER**

## MODEL ER-A610

SRV Key: LKGIM7113RCZZ

PRINTER: M-820 (For "V" version)

## CAUTION

EXTREME CAUTION MUST BE TAKEN WHEN SERVICING THIS MACHINE. EVEN THOUGH THE MODE SWITCH IS IN THE  $\oplus$  POSITION, VOLTAGE IS STILL SUPPLIED TO THE ENTIRE MACHINE.

WHEN WORKING ON THIS MACHINE MAKE SURE THAT THE POWER CORD IS REMOVED FROM THE WALL OUTLET.

_		CONTENTS
	CHAPTER 1	. GENERAL1
	CHAPTER 2	LIST OF OPTIONS
	CHAPTER 3	REMOVING THE MAIN DRAWER
	CHAPTER 4	. REMOVING THE TOP CABINET3
	CHAPTER 5	EXPANSION RAM CHIP and RAM BOARD (ER-01RA, ER-02RA, ER-01MB and ER-02MB)
	CHAPTER 6	. CONTROL ROM (ER-A61R1)7
		. IN-LINE I/F (ER-A6IN) and RS232 I/F (ER-A5RS)8
		. REMOTE DRAWER (ER-03DW)12
		. SLIP PRINTER (ER-31SP)14
		HAND SCANNER (ER-A6HS1)18
		JOURNAL NEAR END SENSOR (DKIT-8643RCZZ)19
		DRAWER FIXING KIT (DKIT-8633RCZZ)20
		PRESETS LOADER21

Parts marked with "A" is important for maintaining the safety of the set. Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

This is a "Table of Contents preview" for quality assurance

The full manual can be purchased from our store:

https://the-checkout-tech.com/manuals/sharp/ER-A610 installation manual.html

And our free Online Keysheet maker:

https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/

HTTPS://THE-CHECKOUT-TECH.COM