

SHARP SERVICE MANUAL

CODE: 00ZERA61VOSME

ER-A610 OPTION

SRN (IN-LINE) INTERFACE

ER-A6IN

RS-232 INTERFACE

ER-A5RS

CONTROL ROM

MODEL ER-A61R1

(For "V" version)

CONTENTS

- I. SRN (IN-LINE) SYSTEM FOR ER-A610 1-1
- II. RS-232 SYSTEM FOR ER-A610 2-1
- III. TEST FUNCTION FOR ER-A6IN AND ER-A5RS 3-1
- IV. HARDWARE DESCRIPTION FOR ER-A6IN AND ER-A5RS 4-1

PARTS GUIDE

Parts marked with "△" is important for maintaining the safety of the set. Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

I. SRN (IN-LINE) SYSTEM FOR ER-A610

ER-A61IN **MODEL ER-A61R1 (For ER-A610)**

(OPTIONS FOR ER-A610)

CONTENTS

CHAPTER 1. ER-A610 SRN (IN-LINE) SYSTEM CONFIGURATION	1-2
CHAPTER 2. HARDWARE REQUIREMENTS	1-2
CHAPTER 3. TRANSMISSION SYSTEM SPECIFICATIONS	1-3
CHAPTER 4. FILE/DATA ALLOCATION IN THE IN-LINE SYSTEM	1-6
CHAPTER 5. PROGRAM DATA UPDATING	1-6
CHAPTER 6. SRV-MODE PROGRAMMING	1-9
CHAPTER 7. PGM2 MODE PROGRAMMING	1-15
CHAPTER 8. TROUBLESHOOTING JOBS	1-17
CHAPTER 9. READING (X) AND RESETTING (Z) REPORTS	1-18
CHAPTER 10. SOFTWARE INSTALLATION PROCEDURE FOR IN-LINE SYSTEM	1-20

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)