


SHARP SERVICE MANUAL

CODE: 00ZERA650VSME



ELECTRONIC CASH REGISTER

MODEL ER-A650

SRV Key : LKGIM7113RCZZ
PRINTER: M-820
(For "V" version)

CAUTION
EXTREME CAUTION MUST BE TAKEN WHEN SERVICING THIS MACHINE. EVEN THOUGH THE MODE SWITCH IS IN THE \odot POSITION, VOLTAGE IS STILL SUPPLIED TO THE ENTIRE MACHINE.
WHEN WORKING ON THIS MACHINE MAKE SURE THAT THE POWER CORD IS REMOVED FROM THE WALL OUTLET.

CONTENTS

CHAPTER 1. SPECIFICATIONS	1
CHAPTER 2. OPTIONS	5
CHAPTER 3. SRV. RESET AND MASTER RESET	8
CHAPTER 4. HARD WARE DESCRIPTION	9
CHAPTER 5. TEST FUNCTION	29
CHAPTER 6. DOWN LOAD FUNCTION	38
CHAPTER 7. SERVICE PRECAUTION	40
CHAPTER 8. CIRCUIT DIAGRAM & PWB LAYOUT	42

PARTS GUIDE

Parts marked with " \triangle " is important for maintaining the safety of the set. Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/sharp/ER-A650 service manual.html](https://the-checkout-tech.com/manuals/sharp/ER-A650%20service%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)