


SHARP INSTALLATION MANUAL

CODE: 00ZERA650VIME




ELECTRONIC CASH REGISTER

MODEL ER-A650

SRV Key : LKGIM7113RCZZ
 PRINTER: M-820
 (For "V" version)

CAUTION

EXTREME CAUTION MUST BE TAKEN WHEN SERVICING THIS MACHINE. EVEN THOUGH THE MODE SWITCH IS IN THE  POSITION, VOLTAGE IS STILL SUPPLIED TO THE ENTIRE MACHINE.

WHEN WORKING ON THIS MACHINE MAKE SURE THAT THE POWER CORD IS REMOVED FROM THE WALL OUTLET.

CONTENTS

CHAPTER 1. GENERAL	1
CHAPTER 2. LIST OF OPTIONS	1
CHAPTER 3. REMOVING THE TOP CABINET	3
CHAPTER 4. EXPANSION RAM CHIP and RAM BOARD (ER-01RA, ER-02RA, ER-01MB and ER-02MB)	4
CHAPTER 5. CONTROL ROM (ER-A65R1)	7
CHAPTER 6. IN-LINE I/F (ER-A6IN) and RS232 I/F (ER-A5RS)	8
CHAPTER 7. OPTION DRAWER (ER-A6DW) and REMOTE DRAWER (ER-03DW)	12
CHAPTER 8. SLIP PRINTER (ER-31SP)	15
CHAPTER 9. WMF CLERK KEY I/F (ER-A6WF)	20
CHAPTER 10. JOURNAL NEAR END SENSOR (DKIT-8643RCZZ)	22
CHAPTER 11. DRAWER FIXING KIT (DKIT-8633RCZZ)	23
CHAPTER 12. PRESETS LOADER	24

Parts marked with "△" is important for maintaining the safety of the set. Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)