


# SHARP PROGRAMMING MANUAL

CODE: 00ZERA750VPME



## POS TERMINAL

### MODEL ER-A750

(For "V" version)

#### CONTENTS

CHAPTER 1. SRV RESET (Program Loop Reset) and switch to SRV mode . . .	1
CHAPTER 2. MASTER RESET . . . . .	2
CHAPTER 3. READING OF SRV MODE PROGRAM . . . . .	4
CHAPTER 4. SRV MODE PROGRAMMING . . . . .	15
CHAPTER 5. IRC SETTING . . . . .	47

\* For setting in PGM1 or PGM2 mode, refer to the Operation Manual.

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/sharp/ER-A750 programming manual.html](https://the-checkout-tech.com/manuals/sharp/ER-A750%20programming%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)