


SHARP PROGRAMMING MANUAL

CODE: 00ZERA750VPME



POS TERMINAL

MODEL ER-A750

(For "V" version)

CONTENTS

CHAPTER 1. SRV RESET (Program Loop Reset) and switch to SRV mode . . .	1
CHAPTER 2. MASTER RESET	2
CHAPTER 3. READING OF SRV MODE PROGRAM	4
CHAPTER 4. SRV MODE PROGRAMMING	15
CHAPTER 5. IRC SETTING	47

* For setting in PGM1 or PGM2 mode, refer to the Operation Manual.

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

https://the-checkout-tech.com/manuals/cashregisters/Sharp_ER-A750_programming_manual.html

Checkout our free online Keysheet Maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

THE-CHECKOUT-TECH.COM