


# SHARP SERVICE MANUAL

CODE: 00ZERA750VSME



## MODEL ER-A750 (For "V" version)

### CONTENTS

CHAPTER 1. SPECIFICATIONS .....	1-1
CHAPTER 2. OPTIONS .....	2-1
CHAPTER 3. SERVICE PRECAUTION .....	3-1
CHAPTER 4. SRV RESET (Program Loop Reset) and switch to SRV mode .....	4-1
CHAPTER 5. MASTER RESET .....	5-1
CHAPTER 6. DIAGNOSTICS SPECIFICATIONS .....	6-1
CHAPTER 7. CIRCUIT DESCRIPTION .....	7-1
CHAPTER 8. CIRCUIT DIAGRAM .....	8-1
CHAPTER 9. PWB LAYOUT .....	9-1
PARTS GUIDE	

Parts marked with "△" is important for maintaining the safety of the set. Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)