


# SHARP SERVICE MANUAL

CODE : 00ZERA770USME



## MODEL ER-A770

(For "U" & "A" version)

### CONTENTS

CHAPTER 1. SPECIFICATIONS .....	1 - 1
CHAPTER 2. OPTIONS .....	2 - 1
CHAPTER 3. SERVICE PRECAUTION .....	3 - 1
CHAPTER 4. SRV RESET (Program Loop Reset) and switch to SRV mode ...	4 - 1
CHAPTER 5. MASTER RESET .....	5 - 1
CHAPTER 6. DIAGNOSTICS SPECIFICATIONS .....	6 - 1
CHAPTER 7. CIRCUIT DESCRIPTION .....	7 - 1
CHAPTER 8. CIRCUIT DIAGRAM .....	8 - 1
CHAPTER 9. PWB LAYOUT .....	9 - 1
PARTS GUIDE	

Parts marked with "△" are important for maintaining the safety of the set. Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*