

SHARP SERVICE MANUAL

CODE: 00ZPR58MASM/E

THERMAL PRINTER

PR-58M PR-58A MODEL ER-01AC

PR-58M: MANUAL CUTTER
PR-58A: AUTO CUTTER
ER-01AC: AUTO CUTTER OPTION
FOR PR-58M

CONTENTS

CHAPTER 1. SPECIFICATIONS	1
CHAPTER 2. OUTLINE OF DRIVING CIRCUIT	3
CHAPTER 3. HANDLING THE PRINTER	5
CHAPTER 4. MAINTENANCE	7
CHAPTER 5. TROUBLESHOOTING	8
CHAPTER 6. DISASSEMBLY AND ASSEMBLY	12
CHAPTER 7. INSTALLATION OF THE ER-01AC (AUTO CUTTER UNIT) ...	20
CHAPTER 8. PWB LAYOUT	21
PARTS GUIDE	

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)