
## SHARP PROGRAMMING MANUAL

CODE: 00ZUP3301UPME



## **POS TERMINAL**

## **MODEL UP-3301**

("U & A" version)

## **CONTENTS**

CHAPTER 1. PROGRAM RESET and SRV mode
CHAPTER 2. MASTER RESET (All Memory Clear)
CHAPTER 3. READING OF SRV PROGRAM
CHAPTER 4. SRV MODE PROGRAMMING ("2 SETTING")
CHAPTER 5. SRV MODE PROGRAMMING ("3 IRC SETTING") 29
<ul> <li>For settings in the USER PROGRAMMING mode, please refer to the applicable Reference Manual which is provided for the UP3301 model POS terminal.</li> </ul>

Parts marked with " $\Lambda$ " are important for maintaining the safety of the set. Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

This is a "Table of Contents preview" for quality assurance

The full manual can be found at <a href="http://the-checkout-tech.com/estore/catalog/">http://the-checkout-tech.com/estore/catalog/</a>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<u>http://the-checkout-tech.com</u>: the biggest supplier of cash register and scale manuals on the net