


SHARP PROGRAMMING MANUAL

CODE : 00ZUP3301VP2E



POS TERMINAL

MODEL UP-3301

(For "V" version)

CONTENTS

CHAPTER 1. PROGRAM RESET and SRV mode	1
CHAPTER 2. MASTER RESET (All Memory Clear)	2
CHAPTER 3. READING OF SRV PROGRAM	4
CHAPTER 4. SRV MODE PROGRAMMING ("2 SETTING")	9
CHAPTER 5. SRV MODE PROGRAMMING ("3 IRC SETTING")	48

* For settings in the USER PROGRAMMING mode, please refer to the applicable Reference Manual which is provided for the UP3301 model POS terminal.

Parts marked with "△" are important for maintaining the safety of the set. Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)