

SHARP[®]
POS TERMINAL

MODEL
UP-3500

**INTER-REGISTER
COMMUNICATION SYSTEM**

**INSTRUCTION
MANUAL**

TABLE OF CONTENTS

	Page
■ Introduction	3
1 Inline Operation	4
1. Message display	4
(1) The message displayed during inline communications	4
(2) Error messages	5
2. Open store operation — master and satellite	6
3. Close store operation — master and satellite	7
4. Sign-on operation (cashier assignment)	8
5. Cashier sign-on report (PGM2 mode)	9
6. Sign-off operation (cancellation of cashier assignment)	10
7. Look-up and updating of the GLU file	11
(1) Centralized GLU file system	11
(2) Individual GLU file system	11
8. Drive-thru function	12
(1) Centralized file system	12
(2) Individual file system	12
9. T-Log polling	13
10. Communication with a remote printer (option)	14
(1) Second (back-up) remote printer	14
(2) Remote printer send function	14
(3) Priority printing function	14
11. Rerouting receipt/journal print data	15
2 Consolidated and Individual Reports	16
1. Operating modes	16
2. Consolidated reports — master	17
■ How to take a reading (X1, X2, X3, X4 or OPX) or resetting (Z1, Z2, Z3, Z4 or OPZ) report	17
■ Report list (system)	18
3. Individual reports — master/back-up master/satellite	21
■ How to take a reading (X1, X2, X3, X4 or OPX) or resetting (Z1, Z2, Z3, Z4 or OPZ) report	21
■ Report list (individual)	22
4. Cashier report	25
3 IRC Programming	26
1. Setting the machine numbers — master and satellite	27
2. Setting the IRC machine numbers and parameters — master	28
3. Setting the IRC machine numbers and parameters — satellite	29
4. Reading the contents of the IRC programming — master and satellite	30
5. Downloading the contents of the IRC programming — master	31
(1) Initial downloading	31
(2) Maintenance downloading	31

	Page
6. Programming for the remote printer — master and satellite	34
(1) Assigning kitchen printer numbers to remote printers	34
(2) Specifying the format of chit printing	35
(3) Reading the contents of the remote printer programming	35
7. Downloading the contents of the remote printer programming — master	36
8. Programming for the Manager Work Station (MWS) — master and satellite	37
(1) Programming of the terminal number and the time-out time	37
(2) Reading the contents of the Manager Work Station (MWS) programming	38
4 System Back-Up	39
1. How the IRC back-up system works	39
(1) When the master fails	39
(2) When the master recovers from a failure — Recovery declaration at the master	40
5 Error Recovery	41
1. Data clear operation	41
2. System retry function	42
BASIC SPECIFICATIONS	43

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/sharp/UP-3500 IRC instruction manual.html](https://the-checkout-tech.com/manuals/sharp/UP-3500%20IRC%20instruction%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)