


# SHARP PROGRAMMING MANUAL

CODE : 00ZUP600UPM/E



UP-600

UP-700

## UP-600 MODEL UP-700

(For "U" &amp; "A" version)

### CONTENTS

CHAPTER 1. SRV. RESET AND MASTER RESET .....	2
CHAPTER 2. READING OF THE SRV MODE PROGRAM .....	3
CHAPTER 3. SRV MODE PROGRAMMING ("2 SETTING").....	10
CHAPTER 4. SRV MODE PROGRAMMING ("3 IRC SETTING").....	45
CHAPTER 5. SRV MODE PROGRAMMING ("4 DOWN LOAD") .....	48
CHAPTER 6. SRV MODE PROGRAMMING ("5 DIAGNOSTICS").....	49

\* For settings in PGM1 or PGM2 mode, please refer to the Operation Manual.

Parts marked with "△" are important for maintaining the safety of the set. Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/sharp/UP-600 and UP-700 programming U and A](https://the-checkout-tech.com/manuals/sharp/UP-600%20and%20UP-700%20programming%20U%20and%20A)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)