


SHARP SERVICE MANUAL

CODE : 00ZUP600VSM/E



UP-700

UP-600

UP-600 MODEL UP-700

SRV Key : LKGIM7113RCZZ
 PRINTER : PR-58HA
 (For "V" version)

CONTENTS

CHAPTER 1. SPECIFICATIONS	1 - 1
CHAPTER 2. OPTIONS	2 - 1
CHAPTER 3. SERVICE PRECAUTION	3 - 1
CHAPTER 4. SRV. RESET AND MASTER RESET	4 - 1
CHAPTER 5. DIAGNOSTICS SPECIFICATIONS.....	5 - 1
CHAPTER 6. CIRCUIT DESCRIPTION	6 - 1
CHAPTER 7. CIRCUIT DIAGRAM.....	7 - 1
CHAPTER 8. PWB LAYOUT.....	8 - 1
PARTS GUIDE	

Parts marked with "△" are important for maintaining the safety of the set. Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)