

SHARP SERVICE MANUAL

CODE : 00ZUP600USM/E



MODEL UP-600

SRV Key : LKGIM7113RCZZ
 PRINTER : DP-750
 (For "U & A" version)

CONTENTS

| | |
|--|-------|
| CHAPTER 1. SPECIFICATIONS | 1 - 1 |
| CHAPTER 2. OPTIONS | 2 - 1 |
| CHAPTER 3. SERVICE PRECAUTION | 3 - 1 |
| CHAPTER 4. SRV. RESET AND MASTER RESET | 4 - 1 |
| CHAPTER 5. DIAGNOSTICS SPECIFICATIONS..... | 5 - 1 |
| CHAPTER 6. CIRCUIT DESCRIPTION | 6 - 1 |
| CHAPTER 7. TCP/IP I/F PWB DESCRIPTION..... | 7 - 1 |
| CHAPTER 8. CIRCUIT DIAGRAM..... | 8 - 1 |
| CHAPTER 9. PWB LAYOUT | 9 - 1 |
| PARTS GUIDE | |

Parts marked with "△" are important for maintaining the safety of the set. Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*