

SHARP SERVICE MANUAL

CODE: 00ZUPP16DPSME

CUSTOMER DISPLAY

MODEL UP-P16DP

CONTENTS

1. General	1
2. Circuit description	1
3. Circuit diagram	5
4. PWB layout	7
5. How to Extend Display Pole	7
Parts guide	

Parts marked with "△" is important for maintaining the safety of the set. Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)