

# SHARP SERVICE MANUAL

CODE: 00ZUPT80BPVSM

## ECR / POS OPTION THERMAL LINE PRINTER

### MODEL **UP-T80BP**

PRINTER : LPT2342D

(For "V" version)

#### CONTENTS

CHAPTER 1. SPECIFICATIONS .....	1-1
CHAPTER 2. OPTIONS .....	2-1
CHAPTER 3. INITIAL PROCESSING .....	3-1
CHAPTER 4. COMMAND DESCRIPTION .....	4-1
CHAPTER 5. CHARACTER DESCRIPTION .....	5-1
CHAPTER 6. HEXADECIMAL DUMP .....	6-1
CHAPTER 7. ERROR HANDLING .....	7-1
CHAPTER 8. INSTALLATION .....	8-1
CHAPTER 9. DIAG FUNCTION .....	9-1
CHAPTER 10. IPL (Initial Program Loading) MODE .....	10-1
CHAPTER 11. HARDWARE DESCRIPTION .....	11-1
CHAPTER 12. CIRCUIT DIAGRAM & PWB LAYOUT .....	12-1
PARTS GUIDE	

Parts marked with "△" is important for maintaining the safety of the set. Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

<https://the-checkout-tech.com/manuals/sharp/UP-T80BP> internal printer service manual.

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)