

SHARP SERVICE MANUAL

CODE: 00ZUPT80BPVSM

ECR / POS OPTION THERMAL LINE PRINTER

MODEL **UP-T80BP**

PRINTER : LPT2342D

(For "V" version)

CONTENTS

CHAPTER 1. SPECIFICATIONS	1-1
CHAPTER 2. OPTIONS	2-1
CHAPTER 3. INITIAL PROCESSING	3-1
CHAPTER 4. COMMAND DESCRIPTION	4-1
CHAPTER 5. CHARACTER DESCRIPTION	5-1
CHAPTER 6. HEXADECIMAL DUMP	6-1
CHAPTER 7. ERROR HANDLING	7-1
CHAPTER 8. INSTALLATION	8-1
CHAPTER 9. DIAG FUNCTION	9-1
CHAPTER 10. IPL (Initial Program Loading) MODE	10-1
CHAPTER 11. HARDWARE DESCRIPTION	11-1
CHAPTER 12. CIRCUIT DIAGRAM & PWB LAYOUT	12-1
PARTS GUIDE	

Parts marked with "△" is important for maintaining the safety of the set. Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)