


SHARP PROGRAMMING MANUAL

CODE : 00ZUPX300UPME



POS TERMINAL

MODEL UP-X300

CONTENTS

| | |
|---|---|
| 1. MASTER RESET JOB | 1 |
| A. OVERVIEW | 1 |
| 2. NETWORK SYSTEM INSTALLATION | 1 |
| A. NETWORK CABLING CONNECTION | 1 |
| B. NETWORKED TERMINAL INSTALLATION SEQUENCE | 1 |
| 3. USER INTERFACE | 1 |
| 4. MRS JOB FLOW CHART | 4 |
| 5. POS SERVER AUTHORITY SETTING | 5 |
| 6. APPLICATION INSTALLATION | 6 |
| A. OVERVIEW | 6 |
| B. APPLICATION INSTALLATION FLOW CHART | 6 |
| C. USER INTERFACE | 7 |
| 7. OS VERSION UP | 9 |

Parts marked with "▲" are important for maintaining the safety of the set. Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*