


SHARP SERVICE MANUAL

CODE : 00ZUPX500VSME



POS TERMINAL

MODEL UP-X500

(V version)

CONTENTS

CHAPTER 1. SPECIFICATIONS	1 - 1
CHAPTER 2. OPTIONS	2 - 1
CHAPTER 3. FIXING THE HDD UNIT	3 - 1
CHAPTER 4. DIAGNOSTICS SPECIFICATIONS	4 - 1
CHAPTER 5. CIRCUIT DESCRIPTION	5 - 1
CHAPTER 6. TOUCH PANEL CALIBRATION UTILITY.....	6 - 1
CHAPTER 7. CIRCUIT DIAGRAM	7 - 1

Parts marked with "△" are important for maintaining the safety of the set. Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)