









CONTENTS

Pag	je
hysical Characteristics of the XE-1051 Register	4
nstalling the Paper Roll and Mounting the Take-Up Spool.	5
Ceyboard Layout and Switch and Key Descriptions.	7
Mode switch (serves also as power switch) Keyboard and key functions	
Description of the Display	9
Overflow Error Alarm	0
rogramming	1
 Machine-number (a maximum of 3 digits). Consecutive-number (a maximum of 4 digits). Date setting. Time setting. Automatic updating of date. Example of transaction-time print. Tax programming for the XE-1051. Department and minus keys. Entry digit limit for the manual tax key. Percent key. Printing format and the presence or absence of the time on 	1 1 2 2 2 8 9
the receipt/journal	
12. Reading the contents of programming 2	
arious Registrations	
Single-item registration	
3. Multiple-item registration 2	
	- · 21
5. Multiplication registration 2	22
6. Computation of sub-total	22
7. Manual tax entry	22
8. Tax delete 2	22
9. Tax shift	23
10. Percent calculation	23
11 Amount-tendered registration	24

14. Paid-out registration

12. Charge sale.2513. Received-on-account registration.25

25

Page
Correction
Correction of entered numbers
 Correction right after a registration (direct void)
Cancellation (in VOID Mode) after the End of a Transaction
(after the Issuance of a Receipt)
Reading and Resetting of Sales
In Case of Power Failure
Locking the Drawer
Removing the Till and the Drawer.
Opening the Drawer manually
Replacing the Paper Roll and Removing the Paper Take-Up Spool
Replacing the Ink Ribbon
Before Calling for Service
Specifications

Option

This is a "Table of Contents preview" for quality assurance

The full manual can be found at http://the-checkout-tech.com/estore/catalog/

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<u>http://the-checkout-tech.com</u>: the biggest supplier of cash register and scale manuals on the net