

SHARP®

SHARP ELECTRONIC CASH REGISTER

MODEL

XE-1055

INSTRUCTION MANUAL



CONTENTS

	Page
Physical Characteristics of the XE-1055 Register	5
Keyboard Layout and Switch and Key Descriptions	6
1. Mode switch (serves also as the power switch)	6
2. Keyboard layout and key functions	7
Description of the Display	8
Overflow Error Alarm	10
Installing the Paper Roll and Mounting the Take-Up Spool	11
Programming	13
1. Machine number	13
2. Consecutive number	13
3. Tax programming	14
4. Department and minus keys	18
5. Entry digit limit for the manual tax key	19
6. Percent key	20
7. Printing format and printing of the time on the receipt/journal	20
8. Price lookup (PLU) programming	21
9. Entry digit limit for the charge, RA, and PO keys	22
10. Reading the contents of programming	22
Date and Time Setting	24
1. Date setting	24
2. Time setting	24
3. Time display	25
4. Automatic updating of date	25
Various Registrations	26
1. Single-item registration	26
2. Registration of single-item cash sale	27
3. Multiple-item registration	27
4. Repetitive registration	27
5. Multiplication registration	28
6. Computation of subtotal	28
7. Finalization of transaction	29
(1) Change calculations	29
(2) Charge sale	29
(3) Mixed tender sale (cash tendering + charge sale)	29
8. Automatic tax	30
9. Manual tax entry	30
10. Tax delete	30
11. Tax shift	31
12. Percent calculation	31
(1) Percent calculation for item entries	31
(2) Percent calculation for merchandise subtotal	32
13. Discount entries	32
14. Refund entries	32
15. Printing of non-add code numbers	33
16. No-sale (exchange)	33
17. Received-on-account and paid-out registration	33

	Page
Correction	34
1. Correction of entered numbers	34
2. Correction of the last entry (direct void)	34
3. Correction of the next-to-last or earlier entries (indirect void)	35
Cancellation (in VOID Mode) after the End of a Transaction (after the issuance of a Receipt)	35
Reading and Resetting of Sales	36
1. Reading of sales	36
2. Reading and resetting of sales	36
In Case of Power Failure	38
Locking the Drawer	38
Removing the Drawer	39
Opening the Drawer Manually	39
Replacing the Paper Roll and Removing the Paper Take-up Spool	40
Replacing the Ink Ribbon	41
Before Calling for Service	42
Specifications	43

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*