



SHARP ELECTRONIC CASH REGISTER  
CAJA REGISTRADORA ELECTRONICA DE SHARP

MODEL **XE-A110**  
MODELO **XE-A115**

INSTRUCTION MANUAL

MANUAL DE INSTRUCCIONES



The above illustration shows model XE-A115.

**[English]**

**Parts and Their Functions ..... 4**  
Mode Switch ..... 4  
Keyboard Layout ..... 4  
Display ..... 5  
**Before Operation ..... 5**  
Reset the Cash Register ..... 5  
Install Batteries..... 6  
Install the Paper Roll ..... 6  
Set the Time and Date ..... 7  
Check the Time and Date ..... 8  
Program Tax ..... 8  
Program Departments ..... 10  
Program PLUs ..... 10  
Program Other Items as Necessary ..... 11  
**When an Error Occurs ..... 11**  
Error Escape Function..... 11  
**Typical Operation Examples ..... 12**  
When Paid by Cash ..... 12  
When Paid by a Credit Card ..... 12  
When Paid by Check..... 12  
Mixed Tender Sale..... 13  
**Corrections ..... 13**  
Correction of Entered Numbers..... 13  
Correction of the Last Entry (Direct Void) ..... 13  
Correction of Earlier Entries (Indirect Void) ..... 14  
**Repetitive Entries..... 14**  
Repetitive Department Entries ..... 14  
Multiplication Entries ..... 14  
**Department ..... 15**  
Programming a Preset Unit Price ..... 15  
Programming the Department Status ..... 15  
Operation Using a Preset Unit Price ..... 16  
Single Item Cash Sale (SICS) Entry ..... 16  
**PLU ..... 17**  
Programming..... 17  
Entry ..... 17  
**Tax Calculation ..... 18**  
Taxable Subtotal..... 18  
Automatic Tax Calculation ..... 18  
Tax Shift ..... 18  
Tax Delete ..... 19  
Manual Tax ..... 19  
**Opening the Drawer with No Sale ..... 19**  
**Percent Key ..... 19**  
Programming Percent Key Function ..... 20  
Programming Percent rate ..... 20  
Discounts and Premiums Using the Percent Key ..... 21  
**Minus Key (XE-A115 only) ..... 21**  
Programming a Preset Reduction Amount ..... 21  
Programming the Minus Key Status ..... 22  
Discounts Using the Minus Key ..... 22

<b>Non-add Code Number</b> .....	<b>23</b>
<b>Received-on-Account and Paid-Out Entries</b> .....	<b>23</b>
<b>Entering a Refund</b> .....	<b>23</b>
<b>Receipt Number</b> .....	<b>24</b>
<b>Printing Format</b> .....	<b>24</b>
<b>Miscellaneous Settings</b> .....	<b>25</b>
<b>Secret Code</b> .....	<b>26</b>
<b>Checking the Machine Settings</b> .....	<b>27</b>
General & Tax Settings.....	27
PLU Settings .....	27
<b>Reading and Resetting of Sales</b> .....	<b>28</b>
X Reports for Reading of Sales .....	28
Z Reports for Reading and Resetting of Sales (without resetting GT) .....	28
Z Reports for Reading and Resetting of Sales (with resetting of GT) .....	28
Flash Reports for Viewing on the Display .....	28
<b>Basic Calculator Function</b> .....	<b>30</b>
Calculation Examples .....	30
Using the Memory Key .....	30
<b>Drawer Handling</b> .....	<b>31</b>
Locking the Drawer .....	31
Removing the Drawer.....	31
Manually Opening the Drawer .....	31
<b>Maintenance</b> .....	<b>31</b>
Batteries .....	31
Paper Roll .....	32
Ink Roller .....	33
<b>In Case of Power Failure or Paper Jam</b> .....	<b>33</b>
<b>Before Calling for Service</b> .....	<b>34</b>
<b>Specifications</b> .....	<b>34</b>

## **Español**

<b>Antes del funcionamiento</b> .....	<b>35</b>
<b>Ejemplos de funcionamiento</b> .....	<b>36</b>
<b>Sección</b> .....	<b>37</b>
<b>PLU</b> .....	<b>37</b>
<b>Cálculo de impuestos</b> .....	<b>37</b>
<b>Para abrir el cajón sin venta</b> .....	<b>38</b>
<b>Tecla de porcentaje</b> .....	<b>38</b>
<b>Tecla de "menos" (XE-A115 solamente)</b> .....	<b>38</b>
<b>Número de código de no suma</b> .....	<b>39</b>
<b>Registros de recibido a cuenta y pagos</b> .....	<b>39</b>
<b>Registro de una devolución</b> .....	<b>39</b>
<b>Número de recibo</b> .....	<b>39</b>
<b>Formato de impresión</b> .....	<b>39</b>
<b>Ajustes varios</b> .....	<b>39</b>
<b>Código secreto</b> .....	<b>40</b>
<b>Comprobación de los ajustes de la máquina</b> .....	<b>40</b>
<b>Lectura y reposición de las ventas</b> .....	<b>40</b>
<b>Función básica de calculadora</b> .....	<b>40</b>
<b>Mantenimiento</b> .....	<b>40</b>

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/sharp/XE-A110 XE-A115 instruction programming](https://the-checkout-tech.com/manuals/sharp/XE-A110%20XE-A115%20instruction%20programming%20manual.pdf)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)