



SHARP ELECTRONIC CASH REGISTER
CAJA REGISTRADORA ELECTRONICA DE SHARP

MODEL **XE-A110**
MODELO **XE-A115**

INSTRUCTION MANUAL

MANUAL DE INSTRUCCIONES



The above illustration shows model XE-A115.

[English]

Parts and Their Functions 4
Mode Switch 4
Keyboard Layout 4
Display 5
Before Operation 5
Reset the Cash Register 5
Install Batteries..... 6
Install the Paper Roll 6
Set the Time and Date 7
Check the Time and Date 8
Program Tax 8
Program Departments 10
Program PLUs 10
Program Other Items as Necessary 11
When an Error Occurs 11
Error Escape Function..... 11
Typical Operation Examples 12
When Paid by Cash 12
When Paid by a Credit Card 12
When Paid by Check..... 12
Mixed Tender Sale..... 13
Corrections 13
Correction of Entered Numbers..... 13
Correction of the Last Entry (Direct Void) 13
Correction of Earlier Entries (Indirect Void) 14
Repetitive Entries..... 14
Repetitive Department Entries 14
Multiplication Entries 14
Department 15
Programming a Preset Unit Price 15
Programming the Department Status 15
Operation Using a Preset Unit Price 16
Single Item Cash Sale (SICS) Entry 16
PLU 17
Programming..... 17
Entry 17
Tax Calculation 18
Taxable Subtotal..... 18
Automatic Tax Calculation 18
Tax Shift 18
Tax Delete 19
Manual Tax 19
Opening the Drawer with No Sale 19
Percent Key 19
Programming Percent Key Function 20
Programming Percent rate 20
Discounts and Premiums Using the Percent Key 21
Minus Key (XE-A115 only) 21
Programming a Preset Reduction Amount 21
Programming the Minus Key Status 22
Discounts Using the Minus Key 22

Non-add Code Number	23
Received-on-Account and Paid-Out Entries	23
Entering a Refund	23
Receipt Number	24
Printing Format	24
Miscellaneous Settings	25
Secret Code	26
Checking the Machine Settings	27
General & Tax Settings.....	27
PLU Settings	27
Reading and Resetting of Sales	28
X Reports for Reading of Sales	28
Z Reports for Reading and Resetting of Sales (without resetting GT)	28
Z Reports for Reading and Resetting of Sales (with resetting of GT)	28
Flash Reports for Viewing on the Display	28
Basic Calculator Function	30
Calculation Examples	30
Using the Memory Key	30
Drawer Handling	31
Locking the Drawer	31
Removing the Drawer.....	31
Manually Opening the Drawer	31
Maintenance	31
Batteries	31
Paper Roll	32
Ink Roller	33
In Case of Power Failure or Paper Jam	33
Before Calling for Service	34
Specifications	34

Español

Antes del funcionamiento	35
Ejemplos de funcionamiento	36
Sección	37
PLU	37
Cálculo de impuestos	37
Para abrir el cajón sin venta	38
Tecla de porcentaje	38
Tecla de "menos" (XE-A115 solamente)	38
Número de código de no suma	39
Registros de recibido a cuenta y pagos	39
Registro de una devolución	39
Número de recibo	39
Formato de impresión	39
Ajustes varios	39
Código secreto	40
Comprobación de los ajustes de la máquina	40
Lectura y reposición de las ventas	40
Función básica de calculadora	40
Mantenimiento	40

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*