

SHARP[®]

ELECTRONIC CASH REGISTER
ELEKTRONISCHE REGISTRIERKASSE
CAISSE ENREGISTREUSE ELECTRONIQUE
CAJA REGISTRADORA ELECTRONICA
ELEKTRONISCHE KASSA

MODEL
MODELL
MODELE
MODELO
MODEL

XE-A113

INSTRUCTION MANUAL
BEDIENUNGSANLEITUNG
MANUEL D'INSTRUCTIONS

MANUAL DE INSTRUCCIONES
GEBRUIKSAANWIJZING



With Quick Start Guide
Mit Schnellstartanleitung
Avec Guide de démarrage rapide
Con Guía de inicio rápido
Met Gids voor snel starten

CONTENTS

INTRODUCTION	1
IMPORTANT	1
CONTENTS.....	2

Part1 QUICK START GUIDE

STEP1 PARTS AND THEIR FUNCTIONS	5
1 External View	5
2 Printer	5
3 Mode Switch and Mode Keys	6
4 Keyboard	6
5 Displays	7
6 Drawer Lock Key	7
STEP2 PREPARING THE CASH REGISTER	8
1 Initializing the Cash Register	8
2 Installing Batteries	9
3 Installing a Paper Roll	10
STEP3 HELP FUNCTION	12
STEP4 BASIC FUNCTION PROGRAMMING.....	13
1 Abbreviations and Terminology	13
2 Prior to Programming	13
Procedure for programming	13
Description of special keys	13
Guidance for text programming	14
3 Language Selection.....	15
4 Date and Time Programming	15
5 Tax Programming	16
6 Department Programming	17
7 PLU (Price Look-Up) and Subdepartment Programming	20
8 Text Programming	22
Clerk names	22
Logo messages	22
9 Programming Other Necessary Items	23
STEP5 BASIC SALES ENTRY	24
1 Basic Sales Entry Example	24
2 PLU Entry	25
STEP6 CORRECTION	26
1 Cancellation of the Numeric Entry	26
2 Correction of the Last Entry (direct void)	26
3 Correction of the Next-to-last or Earlier Entry (indirect void)	27
4 Subtotal Void	27
5 Correction of Incorrect Entries not Handled by the Direct or Indirect Void Function	28
STEP7 FULL SALES REPORT (Z REPORT).....	29
STEP8 BEFORE CALLING FOR SERVICE	31
Error code table	31

Part2 FOR THE OPERATOR

OTHER BASIC SALES ENTRIES	32
1 Additional Information for BASIC SALES ENTRY.....	32
2 Error Warning	32
3 Item Entries	33
Single item entries	33
Repeat entries	34
Multiplication entries	35
Single item cash sale (SICS) entry	35
4 Displaying Subtotals	36
5 Finalization of Transaction	36
Cash or cheque tendering	36
Cash or cheque sale that does not require tender entry	36
Credit sale	37
Mixed-tender sale	37
6 Computation of VAT (Value Added Tax)/tax	37
VAT/tax system	37
OPTIONAL FEATURES.....	39
1 Auxiliary Entries.....	39
Percent calculations (premium or discount)	39
Deduction entries.....	39
Refund entries	40
Non-add code number entries and printing	40
2 Auxiliary Payment Treatment	41
Currency exchange	41
Received-on-account entries.....	42
Paid-out entries	42
No sale (exchange)	42
3 Automatic Sequence Key (AUTO key) Entries.....	42

Part3 FOR THE MANAGER

PRIOR TO PROGRAMMING	43
Procedure for programming.....	43
Entering character codes with numeric keys on the keyboard	43
Alphanumeric character code table	44
AUXILIARY FUNCTION PROGRAMMING	45
1 Miscellaneous Key Programming.....	45
Rate for \%1 , \%2 and EX	45
Amount for \Theta	45
Percent rate limitation for \%1 and \%2	46
Function parameters for \%1 , \%2 and \Theta	46
Function parameters for EX	47
Function parameters for RA , ROPT/PO , CH1 , CH2 , CR1 , CR2 and TL/NS (when using as TL key)	48
2 Other Text Programming.....	49
Foreign currency symbol	49
Domestic currency symbol	49
Training mode text.....	50
Function text	50
ADVANCED FUNCTION PROGRAMMING	52
1 Register Number and Consecutive Number Programming	52
2 Various Function Selection Programming 1	53
Function selection for miscellaneous keys	53
Print format	54
Receipt print format	54
Other programming	55
3 Various Function Selection Programming 2	60
Power save mode.....	60
Logo message print format.....	61
Thermal printer density	61
Training clerk specification for training mode	61
AUTO key programming - Automatic sequence key	62
4 EURO Programming	63
5 Reading Stored Programs.....	64
TRAINING MODE	67
READING (X) AND RESETTING (Z) OF SALES TOTALS	68
EJ REPORT READING AND RESETTING	70
OVERRIDE ENTRIES	71
CORRECTION AFTER FINALIZING A TRANSACTION (Void mode).....	71
EURO MIGRATION FUNCTION	72
OPERATOR MAINTENANCE.....	75
1 In Case of Power Failure	75
2 In Case of Printer Error	75
3 Cautions in Handling the Printer and Recording Paper.....	75
4 Replacing the Batteries	76
5 Replacing the Paper Roll.....	76
6 Removing a Paper Jam	78
7 Cleaning the Printer (Print Head / Sensor / Roller)	78
8 Removing the Drawer.....	78
9 Opening the Drawer by Hand.....	78
SPECIFICATIONS	79

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : the biggest supplier of cash register and scale manuals on the net