

Sharp XE-A130 operating programming Manual

SHARP®

SHARP ELECTRONIC CASH REGISTER
SHARP ELEKTRONISCHE REGISTRIERKASSE
CAISSE ENREGISTREUSE ELECTRONIQUE DE SHARP
CAJA REGISTRADORA ELECTRONICA DE SHARP

MODEL
MODELL
MODELE
MODELO

XE-A130

INSTRUCTION MANUAL
BEDIENUNGSANLEITUNG

MANUEL D'INSTRUCTIONS
MANUAL DE INSTRUCCIONES




Table of Contents

Parts and Their Functions	4
Mode Switch	4
Keyboard Layout	4
Display	5
Before Operation	5
Reset the Cash Register	5
Install Batteries	6
Install the Paper Roll	6
Set the-Time and Date	7
Check the Time and Date	8
Program VAT	8
Program Departments	8
Program Other Items as Necessary	9
When an Error Occurs	9
Error Escape Function	9
Typical Operation Examples	10
When Paid by Cash	10
When Paid by Credit	10
When Paid by Cheque	10
Mixed Tender Sale	11
Corrections	11
Correction of Entered Numbers	11
Correction of the Last Entry (Direct Void)	11
Correction of Earlier Entries (Indirect Void)	12
Correction After Issuance of Receipt	12
Repetitive Entries	12
Repetitive Department Entries	12
Multiplication Entries	13
Department	13
Programming a Preset Unit Price	13
Programming the Department Status	13
Operation Using a Preset Unit Price	14
Single Item Cash Sale (SICS) Entry	15
VAT Calculation	15
Opening the Drawer with No Sale	15
Percent Key	16
Programming Percent Key Function	16
Programming Percent Rate	16
Discounts and Premiums Using the Percent Key	16
Minus Key	17
Programming a Preset Reduction Amount	17
Discounts Using the Minus Key	17
Non-add Code Number	18
Received-on-Account and Paid-Out Entries	18
Entering a Refund	19
Receipt Number	19
Printing Format	20
Miscellaneous Settings	21
Secret Code	22

Table of Contents

Checking the Machine Settings	22
General & Tax Settings	22
Reading and Resetting of Sales	23
X Reports for Reading of Sales	23
Z Reports for Reading and Resetting of Sales (without resetting GT)	23
Z Reports for Reading and Resetting of Sales (with resetting of GT)	23
Flash Reports for Viewing on the Display	23
Basic Calculator Function	25
Calculation Examples	25
Using the Memory Key	25
Drawer Handling	26
Locking the Drawer	26
Removing the Drawer	26
Manually Opening the Drawer	26
Maintenance	26
Batteries	26
Paper Roll	27
Ink Roller	28
In Case of Power Failure or Paper Jam	28
Before Calling for Service	29
Specifications	29

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/sharp/XE-A130 operating programming manual.h](https://the-checkout-tech.com/manuals/sharp/XE-A130%20operating%20programming%20manual.h)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)