

Sharp XE-A130 operating programming Manual

**SHARP**®


SHARP ELECTRONIC CASH REGISTER  
SHARP ELEKTRONISCHE REGISTRIERKASSE  
CAISSE ENREGISTREUSE ELECTRONIQUE DE SHARP  
CAJA REGISTRADORA ELECTRONICA DE SHARP

MODEL  
MODELL  
MODELE  
MODELO

**XE-A130**

INSTRUCTION MANUAL  
BEDIENUNGSANLEITUNG

MANUEL D'INSTRUCTIONS  
MANUAL DE INSTRUCCIONES



# Table of Contents

<b>Parts and Their Functions</b> .....	<b>4</b>
Mode Switch .....	4
Keyboard Layout .....	4
Display .....	5
<b>Before Operation</b> .....	<b>5</b>
Reset the Cash Register .....	5
Install Batteries .....	6
Install the Paper Roll .....	6
Set the-Time and Date .....	7
Check the Time and Date .....	8
Program VAT .....	8
Program Departments .....	8
Program Other Items as Necessary .....	9
<b>When an Error Occurs</b> .....	<b>9</b>
Error Escape Function .....	9
<b>Typical Operation Examples</b> .....	<b>10</b>
When Paid by Cash .....	10
When Paid by Credit .....	10
When Paid by Cheque .....	10
Mixed Tender Sale .....	11
<b>Corrections</b> .....	<b>11</b>
Correction of Entered Numbers .....	11
Correction of the Last Entry (Direct Void) .....	11
Correction of Earlier Entries (Indirect Void) .....	12
Correction After Issuance of Receipt .....	12
<b>Repetitive Entries</b> .....	<b>12</b>
Repetitive Department Entries .....	12
Multiplication Entries .....	13
<b>Department</b> .....	<b>13</b>
Programming a Preset Unit Price .....	13
Programming the Department Status .....	13
Operation Using a Preset Unit Price .....	14
Single Item Cash Sale (SICS) Entry .....	15
<b>VAT Calculation</b> .....	<b>15</b>
<b>Opening the Drawer with No Sale</b> .....	<b>15</b>
<b>Percent Key</b> .....	<b>16</b>
Programming Percent Key Function .....	16
Programming Percent Rate .....	16
Discounts and Premiums Using the Percent Key .....	16
<b>Minus Key</b> .....	<b>17</b>
Programming a Preset Reduction Amount .....	17
Discounts Using the Minus Key .....	17
<b>Non-add Code Number</b> .....	<b>18</b>
<b>Received-on-Account and Paid-Out Entries</b> .....	<b>18</b>
<b>Entering a Refund</b> .....	<b>19</b>
<b>Receipt Number</b> .....	<b>19</b>
<b>Printing Format</b> .....	<b>20</b>
<b>Miscellaneous Settings</b> .....	<b>21</b>
<b>Secret Code</b> .....	<b>22</b>

# Table of Contents

<b>Checking the Machine Settings</b> .....	<b>22</b>
General & Tax Settings .....	22
<b>Reading and Resetting of Sales</b> .....	<b>23</b>
X Reports for Reading of Sales .....	23
Z Reports for Reading and Resetting of Sales (without resetting GT) .....	23
Z Reports for Reading and Resetting of Sales (with resetting of GT) .....	23
Flash Reports for Viewing on the Display .....	23
<b>Basic Calculator Function</b> .....	<b>25</b>
Calculation Examples .....	25
Using the Memory Key .....	25
<b>Drawer Handling</b> .....	<b>26</b>
Locking the Drawer .....	26
Removing the Drawer .....	26
Manually Opening the Drawer .....	26
<b>Maintenance</b> .....	<b>26</b>
Batteries .....	26
Paper Roll .....	27
Ink Roller .....	28
<b>In Case of Power Failure or Paper Jam</b> .....	<b>28</b>
<b>Before Calling for Service</b> .....	<b>29</b>
<b>Specifications</b> .....	<b>29</b>

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)