

Sharp XE-A137 and XE-A147 operation and programming Manual

SHARP®

ELECTRONIC CASH REGISTER

MODEL

XE-A137

XE-A147

FULL DETAILED INSTRUCTION MANUAL



CONTENTS

INTRODUCTION	1
IMPORTANT	1
CONTENTS	2
PARTS AND THEIR FUNCTIONS	4
1 External View	4
2 Printer	4
3 Mode Switch and Mode key	5
4 Keyboard	5
5 Display	6
6 Drawer Lock Key	6
PREPARING THE CASH REGISTER	7
1 Initializing the Cash Register	7
2 Installing Batteries	8
3 Installing a Paper Roll	9
HELP FUNCTION	10
BASIC FUNCTION PROGRAMMING	11
1 Abbreviations and Terminology	11
2 Prior to Programming	11
3 Language Selection	13
4 Date and Time Programming	13
5 Tax Programming	14
6 Department Programming	15
7 PLU (Price Look-Up) and Subdepartment Programming	18
8 Text Programming	20
BASIC SALES ENTRY (Example)	22
1 Basic Sales Entry	22
2 PLU Sales Entry	23
CORRECTION	24
1 Cancellation of the Numeric Entry	24
2 Correction of the Last Entry (direct void)	24
3 Correction of the Next-to-last or Earlier Entry (indirect void)	25
4 Subtotal Void	25
5 Correction after Finalizing a Transaction (Void mode)	26
FULL SALES REPORT (X or Z REPORT)	27
OTHER BASIC SALES ENTRIES	29
1 Additional Information for BASIC SALES ENTRY	29
2 Error Warning	29
3 Starting Cash Memory (SCM) Entry	30
4 Item Entries	31
5 Display of Subtotal	34
6 Finalization of Transaction	35
7 Computation of VAT (Value Added Tax)/Tax	37
OPTIONAL FEATURES	39
1 Auxiliary Entries	39
2 Auxiliary Payment Treatment	40
3 Special Printing Function	42
PRIOR TO PROGRAMMING	43
AUXILIARY FUNCTION PROGRAMMING	45
1 Miscellaneous Key Programming	45
2 Other Text Programming	49

ADVANCED FUNCTION PROGRAMMING	52
1 Register Number and Consecutive Number Programming	52
2 Various Function Selection Programming 1.....	53
3 Various Function Selection Programming 2.....	61
4 EURO Programming.....	63
5 Reading Stored Programs	66
READING (X) AND RESETTING (Z) OF SALES TOTALS	68
1 Summary of Reading (X) and Resetting (Z) Reports.....	68
2 Daily Sales Totals	69
EJ REPORT READING AND RESETTING	70
EURO MIGRATION FUNCTION	71
SD CARD FUNCTION	74
OPERATOR MAINTENANCE	76
1 In Case of Power Failure	76
2 In Case of Printer Error.....	76
3 Cautions in Handling the Printer and Recording Paper.....	76
4 Replacing the Batteries.....	77
5 Replacing the Paper Roll.....	78
6 Removing a Paper Jam	79
7 Cleaning the Printer (Printer Head / Sensor / Roller).....	79
8 Removing the Drawer	80
9 Opening the Drawer by Hand	80
BEFORE CALLING FOR SERVICE	81
SPECIFICATIONS	82

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/sharp/XE-A137 and XE-A147 operation and prog](https://the-checkout-tech.com/manuals/sharp/XE-A137%20and%20XE-A147%20operation%20and%20prog)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)