

# SHARP PARTS GUIDE

CODE : 00ZXEA203UPGE



## ELECTRONIC CASH REGISTER

## MODEL **XE-A203**

(U/A version)

### CONTENTS

- 1 Exteriors
  - 2 Keyboard unit
  - 3 Packing material & Accessories
  - 4 Drawer box unit(SJ-415 type)[for U]
  - 5 Drawer box unit(SJ-423 type)[for A]
  - 6 Main PWB unit
  - 7 Key I/F PWB unit
  - 8 Printer I/F PWB unit
  - 9 Pop up PWB unit
  - 10 Main display PWB unit
  - 11 USB PWB unit
  - 12 Articles for consumption
- index

Parts marked with "△" are important for maintaining the safety of the set. be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/sharp/XE-A203 parts guide U and A ver manual.](https://the-checkout-tech.com/manuals/sharp/XE-A203%20parts%20guide%20U%20and%20A%20ver%20manual.pdf)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)