

Sharp XE-A207W XE-A207B XE-A23S Operation Programming Manual

SHARP®

ELECTRONIC CASH REGISTER

MODEL

XE-A207 XE-A23S

INSTRUCTION MANUAL



CONTENTS

INTRODUCTION	1
IMPORTANT	1
CONTENTS	2
1 Parts and Their Functions	6
External View	6
Front view	6
Rear view	6
Printer	7
Keyboard	8
Keyboard layout (for XE-A207)	8
Function key list	8
Keyboard layout (for XE-A23S)	9
Function key list	9
Displays	10
Operator display	10
Customer display	11
Screen save mode	11
2 Selecting an Operating Mode	12
Operating Modes	12
Mode Selection	13
3 Prior to Making Entries	14
Preparations for Entries	14
Receipt paper roll	14
Receipt ON/OFF function	14
Clerk assignment	14
Error Warning	14
Selecting the Function from the Menu	15
HELP/FAQ Function	16
The HELP menu and printing guidance messages	16
The FAQ menu and guidance messages	17
4 Entries	18
Item Entries	18
Single item entries	18
Repeat entries	20
Multiplication entries	21
Split-pricing entries	22
Single item cash sale (SICS)	23
Display of Subtotals	23
Taxable subtotal	23
Including-tax subtotal (complete subtotal)	23
Finalization of Transaction	24
Cash or check tendering	24
Cash or check sale that does not need any tender entry	25
Charge (credit) sale	25
Mixed-tender sale (cash or check tendering + charge tendering)	25
Tax Calculation	26
Automatic tax	26
Manual tax	26
Tax delete	27
Tax status shift	27
Auxiliary Entries	28

Percent calculations (premium or discount)	28
Discount entries	29
Refund entries	29
Printing of non-add code numbers	30
Payment Treatment	30
Currency conversion.....	30
Received-on-account entries	31
Paid-out entries	32
No-sale (exchange)	32
Electronic Journal View	33
TRAINING Mode.....	33
5 Correction	34
Correction of the Last Entry (Direct Void)	34
Correction of the Next-to-Last or Earlier Entries (Indirect Void).....	35
Subtotal Void.....	36
Correction after Finalizing a Transaction	36
6 Special Printing Function	37
Copy Receipt Printing	37
7 Manager Mode	38
Entering the Manager Mode	38
Override Entries.....	38
8 Reading (X) and Resetting (Z) of Sales Totals	39
How to take a X1/Z1 or X2/Z2 report	39
View report.....	39
Daily Sales Totals	41
General report	41
PLU report by designated range.....	42
PLU report by associated department	42
Clerk reports	42
Hourly report.....	42
Periodic Report Sample.....	43
General information	43
9 Prior to Programming	44
Programming Keyboard Layout	44
For XE-A207	44
For XE-A23S	44
How to Program Alphanumeric Characters	46
Mobile phone method	46
Entering character codes.....	47
10 Programming	48
Basic Instructions.....	48
Programming screen	48
Programming example	49
DEPT/PLU Programming.....	51
Department.....	52
PLU.....	53
PLU range	53
Functional Programming.....	54
Discount (⊖).....	55
Percent (%1, %2)	56
Manual tax	56
RA.....	57
PO	57

Cash in drawer	57
Media Key Programming	58
Cash key (Cash).....	58
Check key (Check)	59
Charge key (Charge).....	59
Currency conversion (CONV1, CONV2)	60
Function Text Programming.....	61
Personnel Programming	62
Clerk	62
Manager	63
Mode Pass Code	63
Training Clerk	63
Terminal Programming.....	64
Date/Time Setting	64
Date/time	64
Optional Feature Selection	65
Basic System	66
Function Prohibit.....	67
Function Authority.....	68
Function Selection	69
Print Selection	70
Report Programming	72
Zero skip.....	73
Print select.....	74
Z Counter.....	75
Z1 General report	75
Electronic Journal	75
Message Programming.....	76
Receipt logo.....	76
Device Configuration Programming.....	77
Keyboard	77
Display	78
Printer	78
EFT	78
Tax Programming.....	79
Tax system.....	80
Tax 1 through 4	81
Doughnut exempt	83
Automatic Sequencing Key Programming	84
Key Sequence	84
Reading of Stored Programs	85
Program reading sequence	85
Sample printouts.....	86
EFT Test Function.....	92
SD CARD Mode.....	93
Inserting and removing an SD memory card	93
SD card formatting.....	93
Folder creating.....	93
Folder name selecting	94
Data saving	94
Data loading	95
11 Electronic Journal	96
Electronic journal	96

12 Operator Maintenance	97
In Case of Power Failure	97
In Case of Printer Error	97
Cautions in Handling the Printer and Recording Paper	97
Cautions in handling the printer	97
Cautions in handling the recording paper (thermal paper)	97
Installing Batteries	98
Replacing the Paper Roll	99
Recording paper specifications	99
Installing the Paper Roll	99
Replacing the receipt paper roll	100
Removing a Paper Jam	100
Cleaning the Printer (Printer Head/Sensor/Roller)	101
Removing the Drawer	102
Opening the Drawer by Hand	102
Drawer Lock Key	102
Before Calling for Service	103
13 Specifications	104

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/sharp/XE-A207W XE-A207B XE-A23S Operation](https://the-checkout-tech.com/manuals/sharp/XE-A207W%20XE-A207B%20XE-A23S%20Operation)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://the-checkout-tech.com)