


ELECTRONIC CASH REGISTER

MODEL

XE-A207W/XE-A207B XE-A217W/XE-A217B

FULL DETAILED INSTRUCTION MANUAL



The above illustration shows the model XE-A217W/XE-A217B.

CONTENTS

	TRODUCTION	
	PORTANT	
	DNTENTS	
1	Part Names and Functions	
	External View	
	Front view (XE-A207W/XE-A207B)	
	Front view (XE-A217W/XE-A217B)	
	Rear view (XE-A207W/XE-A207B) (XE-A217W/XE-A217B)	S
	Printer	10
	Keyboard XE-A207W/XE-A207B	11
	Keyboard layout	11
	Function key list	11
	Keyboard XE-A217W/XE-A217B	12
	Keyboard layout	12
	Programing keyboard layout	12
	Function key list	
	Inserting the keyboard sheet (XE-A217W/XE-A217B only)	
	RS232 Connector/SD Card Slot	
	RS232 connector	
	SD card slot	
	Displays	
	Operator display	
	Customer display	
	Screen save mode	
2	Selecting an Operating Mode	
_	Operating Modes	
	Mode Selection	
3		
٠	Preparations for Entries	
	Receipt paper roll	
	Receipt ON/OFF function	
	Clerk assignment	
	~	
	Error Warning Item Selection from the Menu	
	Starting Cash Memory Entry	
	HELP FUNCTION	
	Printing the help menu.	
	Printing guidance messages	
4	Entries	
	Item Entries	
	Single item entries	
	Repeat entries	
	Multiplication entries	
	Split-pricing entries	
	Single item cash sale (SICS)	
	PLU level shift (for direct PLUs) (for XE-A217W/XE-A217B only)	
	Display of Subtotals	
	Subtotal	
	Finalization of Transaction	31
	Cash or check tendering	31
	Mixed tendering (check + cash)	32

	Cash or check sale that does not need any tender entry	
	Credit sale	
	Mixed-tender sale (cash or check tendering + credit tendering)	
	Computation of VAT (Value Added Tax)/Tax	
	VAT/tax system	
	VAT shift entries (for XE-A217W/XE-A217B only)	
	Guest Check	
	Guest look up (GLU) system (for XE-A217W/XE-A217B only)	
	Table bill copy print (for XE-A217W/XE-A217B only)	
	Auxiliary Entries	
	Percent calculations (premium or discount)	
	Discount entries	
	Refund entries	
	Printing of non-add code numbers	
	Payment Treatment	
	Currency exchange	
	Received-on-account entries	
	Paid-out entries	
	No-sale (exchange)	
	Cashing a check	
	Electronic Journal View	
	TRAINING Mode	
5	Correction	
	Correction of the Last Entry (Direct Void)	
	Correction of the Next-to-Last or Earlier Entries (Indirect Void)	
	Subtotal Void	
	Correction after Finalizing a Transaction	
6	Special Printing Function	
	Copy Receipt Printing	
	Guest Check Receipt(Bill Print)	
7	Manager Mode	
	Entering the Manager Mode	
	Override Entries	
8	Reading (X) and Resetting (Z) of Sales Totals	
	How to take a X1/Z1 or X2/Z2 report	
	Flash report	
	Daily Sales Totals	
	General report	
	PLU report by designated range	
	PLU report by associated department	
	Individual clerk report	
	All clerk report	
	Hourly report	
	GLU report (for XE-A217W/XE-A217B only)	
	GLU report by clerk (for XE-A217W/XE-A217B only)	
	Balance report (for XE-A217W/XE-A217B only)	
	Periodic Report Sample	
	General information	
9	Prior to Programming.	
	Programming Keyboard Layout	
	How to Program Alphanumeric Characters	
	Mobile phone method (XE-A207W/XE-A207B only)	
	PC keyboard method (XE-A217W/XE-A217B)	62

Entering character codes	63
10 Programming	64
Basic Instructions	64
Programming screen	64
Programming example	65
Article Programming	67
Department	68
PLU	69
PLU range	70
Functional Programming	71
Discount ()	
Percent ([%1] , %2)	
RA	
PO	74
CID (Cash in drawer)	74
CHK/CG (Check change)	74
Check cashing	75
Media Key Programming	
Cash key (Cash)	
Check key (Check1, Check2)	
Credit key (Credit1, Credit2)	78
Foreign currency (Exchange1, Exchange2)	
Function Text Programming	
Personnel Programming	82
Clerk	82
Manager	
Mode Pass Code	
Training Clerk	
Terminal Programming	
Date/Time Setting	
Date/time	
Optional Feature Selection	
Basic System	
Rounding	
Function Prohibit	90
Function Authority	
Function Selection	
Print Selection	
Exchange Function	
EURO Change	
Report Programming	
Zero skip	
Print select	
Z Counter	
Z1 General report	
Hourly report	
Electronic Journal	
Message Programming.	
Receipt logo	
Device Configuration Programming	
Keyboard	
Display	
Printer	
1 TH ROT	

	Online	102
	Tax Programming	103
	Tax system	103
	Tax 1 through 4	103
	Automatic Sequencing Key Programming	104
	Key Text	104
	Key Sequence	105
	Reading of Stored Programs	106
	Program reading sequence	106
	Sample printouts	107
	SD CARD Mode	115
	Inserting and removing an SD memory card	115
	SD card formatting	115
	Folder creating	115
	Folder name selecting	116
	Data saving	116
	Data loading	117
11	Electronic Journal	118
	Electronic journal	118
12	EURO Migration Function	119
13	Operator Maintenance	121
	In Case of Power Failure	121
	In Case of Printer Error	
	Cautions in Handling the Printer and Recording Paper	121
	Cautions in handling the printer	
	Cautions in handling the recording paper (thermal paper)	121
	Installing Batteries	122
	Replacing the Paper Roll	
	Recording paper specifications	
	Installing the Paper Roll	
	Removing the receipt paper roll	
	Removing the Paper Jam	
	Cleaning the Printer (Printer Head/Sensor/Roller)	
	Removing the Till and the Drawer.	
	Opening the Drawer by Hand	
	Drawer Lock Key	
	Installing the Fixing Angle Bracket	
	Before Calling for Service	
14	Specifications	131

This is a "Table of Contents preview" for quality assurance

The full manual can be purchased from our store:

https://the-checkout-tech.com/manuals/sharp/XE-A207W and XE-A217W and XE-A207E

And our free Online Keysheet maker:

https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/

HTTPS://THE-CHECKOUT-TECH.COM