


SHARP PROGRAMMING MANUAL

CODE : 00ZXEA404UPME



(XE-A404)



(XE-A505)

LEAD-FREE SOLDER MODEL

ELECTRONIC CASH REGISTER

XE-A404 MODEL XE-A505

(For "U" version)

CONTENTS

CHAPTER 1. MASTER RESET AND PROGRAM RESET	1 - 1
CHAPTER 2. PROGRAM (PGM2/PGM1) MODE	2 - 1
CHAPTER 3. OP X/Z, X1/Z1, X2/Z2 MODE	3 - 1

Parts marked with "△" are important for maintaining the safety of the set. Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/sharp/XE-A404 XE-A505 programming U ver ma](https://the-checkout-tech.com/manuals/sharp/XE-A404%20XE-A505%20programming%20U%20ver%20ma)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)