

SHARP SERVICE MANUAL

CODE : 00ZXEA41SUSME

LEAD-FREE SOLDER MODEL



**ELECTRIC
CASH REGISTER**

MODEL XE-A41S

**SRV KEY : Not necessary
PRINTER : PR-45MII**

CONTENTS

■ LEAD-FREE SOLDER

CHAPTER 1. SPECIFICATIONS	1
CHAPTER 2. OPTIONS	4
CHAPTER 3. MASTER RESET AND PROGRAM RESET.....	4
CHAPTER 4. HARDWARE DESCRIPTION	5
CHAPTER 5. DIAGNOSTIC PROGRAM	10
CHAPTER 6. CIRCUIT DIAGRAM AND PWB LAYOUT	15

Parts marked with "△" are important for maintaining the safety of the set. Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/sharp/XE-A41S service manual.html](https://the-checkout-tech.com/manuals/sharp/XE-A41S%20service%20manual.html)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)