

# SHARP SERVICE MANUAL

CODE : 00ZXEA41SUSME

**LEAD-FREE SOLDER MODEL**



## ELECTRIC CASH REGISTER

# MODEL XE-A41S

**SRV KEY : Not necessary**  
**PRINTER : PR-45MII**

### CONTENTS

■ LEAD-FREE SOLDER

CHAPTER 1. SPECIFICATIONS .....	1
CHAPTER 2. OPTIONS .....	4
CHAPTER 3. MASTER RESET AND PROGRAM RESET.....	4
CHAPTER 4. HARDWARE DESCRIPTION .....	5
CHAPTER 5. DIAGNOSTIC PROGRAM .....	10
CHAPTER 6. CIRCUIT DIAGRAM AND PWB LAYOUT .....	15

Parts marked with "△" are important for maintaining the safety of the set. Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*