




TEC Electronic Cash Register

MA-1350-1 SERIES

Owner's Manual



TOSHIBA TEC CORPORATION

TABLE OF CONTENTS

	Page
1. Introduction	1
2. Unpacking	1
3. Outline of Preparation Procedure Before Operating the ECR	2
4. Appearance and Nomenclature	3
5. Control Lock and Control Keys	4
Control Keys	4
Control Lock	4
6. Display	5
Numeric Display	5
Message Descriptors (Status Lamps)	6
7. Keyboard	7
Normal Keyboard Layout	7
Other Optional Keys:	7
Flat Keyboard Layout	8
Other Optional Keys:	8
Functions of Each Key	9
8. Installing the Receipt/Journal Roll	12
Installing the Receipt Roll	12
Installing the Journal Roll	14
9. Installing the Ribbon Cassette	15
10. Daily Operation Flow	16
Before Opening the Store	16
During Business Hours	16
After Closing the Store	16
11. Cashier Identifying Operation	17
1) Signing Method Cashier Sign ON & Sign OFF	17
2) Cashier Key Method (Push LED Key)	18
3) Cashier Key Method (Barrel Lock)	18
4) Cashier Key Method ([CLK] Key)	19
Cashier Reports	19
12. Training	19
Operation for Training Mode Start	19
Entries in Training Mode	20
Operation for Training Mode End	20
13. Transaction Entries	21
Displaying the Time	21
Receipt-issue/Non-issue Selection	21
Clearing Errors, or Clearing Wrong Declaration Key or Wrong Numeric Entries	22
No-sale (Exchange)	22
Received-on-Account Payment	22
Paid Out	23
Department Entries	23
PLU Entries	26
PLU Price Shift Entry	28
Preset Price Open	29

Listing Capacity Open	29
Percent Discount, Percent Charge	30
Dollar Discount	30
Vendor Coupon	31
Store Coupon	31
Item Correct (Last Line Voiding)	32
Void (Designated Line Voiding)	32
All Void (Transaction Cancel)	33
Returned Merchandise	34
Non-add Number Print	34
Subtotal Read	35
Taxable Total Read	35
Finalizing a Sale	35
Food Stamp Tender	37
Previous Balance, Charge Posting	38
Check Cashing (Cashing Non-cash Media)	39
Post-issue Receipt	40
Tax Status Modification	40
Food Stamp Modification	41
Tax Exemption	41
Manual Tax Entry	42
Sale paid in Foreign Currency	42
No-sale Exchange from a Foreign Currency to the Domestic Currency	43
Validation Print	43
Remote Slip Printer (hardware option) Operation	44
14. Paper Roll Replacement and Other Maintenance	46
Replacing the Receipt Roll	46
Replacing the Journal Roll	47
Replacing the Ribbon Cassette	48
Replenishing Ink to the Store Name Stamp	49
Manual Drawer Release and Lock	51
Removing the Drawer	51
Media Slot	52
CDC (Cash Drawer Cover; Option) Lock	52
15. In Case of the Power Failure	53
16. Troubleshooting	53
17. Specifications	57

CAUTION:

1. *This manual may not be copied in whole or in part without prior written permission of TOSHIBA TEC.*
2. *The contents of this manual may be changed without notification.*
3. *Please refer to your local Authorized Service representative with regard to any queries you may have in this manual.*

TABLE OF CONTENTS

	Page
1. Operations in “MGR” Mode	1
Items programmed to require Manager Intervention	1
Listing Capacity Release	2
2. Operations in “ □ ” Mode	3
3. Read and Reset Reports	4
Daily Reports	4
Periodical Reports	5
Report Sample Format	5
4. Changing the Programmed Data	17
Character Entries for Programming Operations:	17
Character Code Entry Method:	18
Direct Character Entry Method:	19
Condition for Programming Operations:	22
Store Message and Commercial Message Programming	23
Cashier Name Programming	26
Department Status Programming	27
PLU Table Setting, Changing, or Deletion	29
Time Setting or Adjustment	32
Date Setting or Adjustment	32
PLU Preset-code Key Setting	33
Department Preset Price Setting or Changing	35
PLU Preset Price Changing	36
% Key Preset Rate Setting or Changing	37
Register No. Setting	38
Foreign Currency Exchange Rate Setting	38
Listing Capacity Setting for Tender Media	39
Vendor Coupon Limit Amount Setting	40
5. Program Data Verification	41
Operating Procedure	41
Appendix	46

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)