

**SCHEMATIC DIAGRAM,  
PARTS LOCATION AND CONNECTION**

**MODEL            MA-136 SERIES**  
**ORIGINAL        MAR.1982**  
**(REVISED        NOV.1982        )**

**DOCUMENT, NO. E6-01099A**

# LOGIC EXPLANATION

**MODEL** MA-136 SERIES

**ORIGINAL** MARCH, 1982

**(REVISED** )

**DOCUMENT No.** E2-01077

**TEC** TOKYO ELECTRIC CO.,LTD.

PRINTED IN JAPAN  
8204950 (D)

———— CONTENTS ————

1. OUTLINE .....	1
2. PC BOARD LOCATION & WIRING .....	2
3. BLOCK DIAGRAM .....	4
4. CIRCUIT EXPLANATION .....	5
4.1 CPU .....	5
(1) CPU .....	5
(2) Keyboard Interface .....	9
(3) Display Interface .....	9
(4) ROM .....	11
(5) RAM .....	11
(6) Printer Controll .....	12
(7) Interface for the CPU and PRC .....	18
(8) Auto Clear / Power Failure Detection Circuit .....	20
(9) Timer Circuit .....	21
(10) Battery .....	22
4.2 FIU .....	23
4.3 POWER UNIT .....	26
4.4 KEYBOARD .....	27
5. SIGNAL DESCRIPTION .....	29
6. APPENDIXES .....	31

# **1. SCHEMATIC DIAGRAM**

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*