ELECTRONIC CASH REGISTER

ET-1420

PROGRAMMING MANUAL

1.	The Pro	graming of Overl	a y	I
2.	Program	ming		3
з.	The Con	tent of Programm	ing at "PGM2" position	4
	3- 1	Programming of	"Main Flag"	· 4
	3-2	Programming of	"Commercial Message"	8
	3-3	Programming of	"Name of Clerk (Cashier) "	10
	3-4	Programming of	"Caption of DPT"	11
	3-5	Programming of	"Caption of PLU"	13
	3-6	Programming of	"Name of Clerk ID"	14
	3-7	Programming of	"Name of Guest "	15
	3-8		"Number of Line Feeds for Slip Printer"-	
	3-9	Programming of	"Number of Max PLU"	17
	3-10	Programming of	"Key Layout"	18
4.			ing at "PGM1" position "Date, Time, Consective No. & Start Time	
			+%,-%,Discount,Tax, Etc"	
	4 - 2		"Price & Flag of DPT"	
	4-3	Programming of	"Price & Flag & Linked DPT of PLU"	28
	4-4		"Tracking Number"	
	4-5	Programming of	"Number of Clerk ID"	33
	4-6	Programming of	"Number of Guest"	34
	4-7	Programming of	"Tax"	35
5.	The Pro	gramming of Stoc	k Q'ty of PLU & DPT	4 0
	5- 1	Programming of	"Quantity of DPT"	41
			"Quantity of PLU"	

This is a "Table of Contents preview" for quality assurance

The full manual can be purchased from our store:

https://the-checkout-tech.com/manuals/towa/ET-1420 programming manual.html

And our free Online Keysheet maker:

https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/

HTTPS://THE-CHECKOUT-TECH.COM