

TOWA

ELECTRONIC CASH REGISTER

MP - 3

INSTRUCTION MANUAL

**Designed for
ease of operation
with total flexibility.**



INDEX

*Keep the followings	2
I. BEFORE USING	3
1. INSTALLATION AND TREATMENT	3
2. names & FUNCTION OF PARTS	4
3. CONTROL KEY	5
4. DISPLAY	6
5. KEY BOARD	8
6. SETTING OR REPLATING ROLL PAPER, RIBBON CASSETTE ETC.	13
7. PRESETTING	15
8. TRAINING MODE	18
II. REGISTERING	19
1. EXAMPLE REGISTEING AND RECEIPTS	19
2. PREVIOUS BALANCE (CHARGING OPERATION)	31
3. BAR-RESTAURANT MODE AND [CLK], [CKPD] KEY ID	33
4. TRANSACTION [HOLD] KEY	34
5. SLIP PRINTER (GUEST CHECK PRINTER)	35
6. RESTAURANT TICKET MODE	41
7. RESTAURANT DOUBLE RECEIPT WITH CONDIMENT KEY	43
8. CHECK ENDORSEMENT	44
9. CASH DECLARATION	45
10. VARIOUS CORRECTIONS AND RETURNS	46
III. REPORTS	47
1. METHOD OF ISSUE A REPORTS	47
2. EXAMPLE REPORTS	49
IV. WHEN THE REGISTER STOPS IN OPERATION.	51
1. MAIN ERROR MESSAGES	51
2. HOW TO RESET THE SYSTEM (TO RELEASE LOCK OF THE MACHINE)	53
*SYSTEM RESET	53

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

<https://the-checkout-tech.com/manuals/towa/ET-8623> and [ET-8626](https://the-checkout-tech.com/manuals/towa/ET-8626) and [Geller MP-3](https://the-checkout-tech.com/manuals/towa/Geller-MP-3) use

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)