

OPTION UNIT
PROGRAMMING MANUAL

Model ME780

Contents

1.	Introduction.....	1
2.	Interface Connectors.....	1
3.	Cable.....	3
4.	Optional Units.....	6
4.1	Bar Code Reader Unit.....	6
4.1.1	Part Names.....	6
4.1.2	Connection.....	6
4.1.3	Operation Procedure.....	6
4.1.4	System Flags related to Bar Code Reader.....	7
4.2	Personal Computer (P.C.).....	9
4.2.1	Necessary Parts.....	9
4.2.2	Connection.....	9
4.2.3	Operation Procedure.....	9
4.3	Modem.....	10
4.3.1	Necessary Parts.....	10
4.3.2	Connection.....	10
4.3.3	Operation Procedure.....	10
4.4	80 Column Dot Printer.....	11
4.4.1	Necessary Parts.....	11
4.4.2	Connection.....	11
4.4.3	Operation Procedure.....	11
4.4.4	System Flags related to 80 Column Dot Printer.....	12
4.5	Slip Printer.....	13
4.5.1	Necessary Parts.....	13
4.5.2	Connection.....	13
4.5.3	Operation Procedure.....	13
4.5.4	System Flags related to Slip Printer.....	14
4.6	Back Up Kitchen Printer for Receipt.....	16
4.6.1	Necessary Parts.....	16
4.6.2	Connection.....	16
4.6.3	Operation Procedure.....	16
4.7	Kitchen (Remote) Printer.....	18
4.7.1	Necessary Parts.....	18
4.7.2	Connection.....	18
4.7.3	Operation Procedure.....	18

4.7.4	System Flags related to Kitchen (Remote) Printer.....	21
4.8	Scale Connection.....	23
4.8.A	OZ Scale.....	23
4.8.A.1	Necessary Parts.....	23
4.8.A.2	Connection.....	23
4.8.A.3	Operation Procedure.....	23
4.8.A.4	System Flags related to the scale.....	28
4.8.B	TERAOKA Scale.....	29
4.8.B.1	Necessary Parts.....	29
4.8.B.2	Connection.....	29
4.8.B.3	Operation Procedure.....	29
4.9	IRC (Inter Register Communication).....	32
4.9.1.	Necessary Parts.....	32
4.9.2.	Connection.....	33
4.9.3.	Operation Procedure.....	35
4.9.4	System Flags related to IRC.....	36
4.9.5	Register Operation.....	37
4.10	Magnetic Card Reader.....	39
4.10.1	Function.....	39
4.10.2	Card Format.....	39
4.10.3	Card Identification Character.....	40
4.10.4	Operation.....	40
4.10.5	System Flags related to Magnetic Card Reader.....	44
4.11	DALLAS Key (I Button).....	45
4.11.1	Function.....	45
4.11.2	Programming Procedure.....	45
4.11.3	Register Position.....	47
4.11.4	System Flags related to DALLAS Key.....	48
4.12	Drawer Inter-connecting Cable.....	49
4.12.1	Connection.....	49
4.12.2	Description.....	49
4.12.3	Cable Diagram.....	50
4.12.4	Connecting	50
4.13	Remote Customer Display.....	51
4.13.1	Necessary Parts.....	51
4.13.2	Before Setting Up.....	51
4.13.3	Steps of Setting Up.....	52
4.13.4	Plugging Device.....	54

[Click here to download the full manual at THE-CHECKOUT-TECH.COM](http://THE-CHECKOUT-TECH.COM)