

OPERATING MANUAL

TOWA NT-1081
GELLER NT-1081

CODE:NT-1081

Contents

NOTICE	
FEDERAL COMMUNICATIONS COMMISSION NOTICE	
Introduction	
Contents	
Overview of Steps Required to Use This Cash Register	

1 Before Starting Operations

1.1 General Specifications.....	1
1.2 Precautions.....	1
1.3 Part Names and Functions.....	2

2 Setting Up

2.1 Installing the Cash Register.....	9
2.2 Initializing Your Cash Register.....	9
2.3 Installing and Removing a Paper Roll.....	10
Installing a Paper Roll.....	10
Removing a Paper Roll.....	11

3 Programming

3.1 Before Programming.....	12
3.2 Setting the Date and Time.....	13
3.3 Setting Department Function Flags.....	14
3.4 Tax Programming.....	15
3.5 Setting System Flags.....	23

4 Cash Register Operation

4.1 Before Operating Your Cash Register.....	27
4.2 Basic Operation.....	28
4.3 Using the [-%] key.....	29
4.4 Charge sale with customer charge number.....	30

4.5 Received on account and Paid out.....	30
4.6 Changing Money and Opening the Drawer.....	31
4.7 Registration with [TAX/SHIFT] key.....	31
4.8 Tax calculations.....	32

5 Making Correction

5.1 Voiding the Last Entry.....	33
5.2 Voiding Earlier Entries.....	33
5.3 Voiding a Sales After the Transaction Has Been Finalized.....	34

6 Checking and Resetting the Sales Information

6.1 Overview of Checking and Resetting Sales Information.....	35
6.2 Sample Reports.....	36

7 Maintenance

7.1 Cleaning Your Cash Register.....	38
7.2 Opening the Drawer Manually.....	38
7.3 Drawer Key.....	38
7.4 Replacing the Ink Roller.....	39
7.5 In Case of a Paper Jam.....	39
7.6 Troubleshooting.....	40

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

<https://the-checkout-tech.com/manuals/towa/NT-1081> and Geller NT-1081 operating pro

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)