SX-585



End User Guide

Retail

INDEX

| Power Switch | 5 |
|---------------------------|---------|
| Rear Display | 6 |
| Cash Drawer | 7 |
| Control Lock | 8 |
| Paper Rolls | 9 – 10 |
| Programming Layout | 11 |
| Reporting Keyboard Layout | 12 |
| Date & Time | 13 |
| Easy Price / Name Change | 14 – 15 |
| Quick Program Changes | 16 – 17 |
| Basic Sales | 18 - 24 |
| Clerk Holds | 25 |
| Reports | 26 - 27 |
| Error Messages | 28 – 29 |
| F.A.Q | 30 |
| Glossary | 31 – 34 |

This is a "Table of Contents preview" for quality assurance

The full manual can be purchased from our store: https://the-checkout-tech.com/manuals/towa/SX-585 and Geller SX-585 user guide Hosp

And our free Online Keysheet maker: https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/

HTTPS://THE-CHECKOUT-TECH.COM