



ELECTRONIC CASH REGISTER

PROGRAMMING MANUAL

Model SX-590II



DEALER LEVEL PROGRAMMING

USER SPECIFIC MAXIMUM / PERIPHERAL PROGRAMMING

CONTENTS

1. HOW TO ENTER THE [SYSTEM(S)] PROGRAMMING MODE.....	1
2. MAXIMUM	2
3. PASSWORD	5
4. I / O TABLE PROGRAM	7
5. SALES DATA CLEAR	10
APPENDIX	11

This is a “Table of Contents preview” for quality assurance

The full manual can be purchased from our store:

[https://the-checkout-tech.com/manuals/towa/SX-590II S mode programming manual.htm](https://the-checkout-tech.com/manuals/towa/SX-590II%20S%20mode%20programming%20manual.htm)

And our free Online Keysheet maker:

<https://the-checkout-tech.com/Cash-Register-Keysheet-Creator/>

[HTTPS://THE-CHECKOUT-TECH.COM](https://THE-CHECKOUT-TECH.COM)